Contract No:

This document was prepared in conjunction with work accomplished under Contract No. DE-AC09-08SR22470 with the U.S. Department of Energy (DOE) Office of Environmental Management (EM).

Disclaimer:

This work was prepared under an agreement with and funded by the U.S. Government. Neither the U.S. Government or its employees, nor any of its contractors, subcontractors or their employees, makes any express or implied:

- 1) warranty or assumes any legal liability for the accuracy, completeness, or for the use or results of such use of any information, product, or process disclosed; or
- 2) representation that such use or results of such use would not infringe privately owned rights; or
- 3) endorsement or recommendation of any specifically identified commercial product, process, or service.

Any views and opinions of authors expressed in this work do not necessarily state or reflect those of the United States Government, or its contractors, or subcontractors.





Steven P. Reynolds, Gregory C. Staack, and Benjamin J. Morgan

Technology of Fusion Energy 2020 Meeting November 17, 2020

SRNL-STI-2020-00533

Outline


LANA Introduction Historically relevant work

- He-3 Release
- Controlled Oxidation **Thermal Stability Testing Path Forward** Acknowledgements




Tritium Aging of LaAl_{4.25}Al_{0.75} (LANA.75)


- LANA beds are limited lifetime components due to decay of tritium to He-3 within the metal matrix
- Tritium aging effects on isotherms
 - Formation of "heel"
 - Inventory hold-up
 - Reduced capacity
 - Decreased plateau pressure
 - Eventual loss of plateau
 - Eventual weeping of He-3




Thermal Release of He-3 from Tritium-Aged LANA



Controlled Oxidation of Tritium-Aged LANA – XRD Results of Argon Testing



Isotherm Results



80°C T₂ LANA.75 Desorption Isotherms

Potential Impacts

If crystallinity is restored, isotherm performance should also be restored. It may be possible to design LANA beds that can be regenerated in place.


Assume:

- 50-year facility life
- ~10 years/bed life
- X beds in the facility

Year	No Regeneration	1 Regeneration	2 Regenerations	4 Regenerations
10	X	-	-	-
20	X	X	-	-
30	X	-	X	-
40	X	X	-	-
Total New Beds	4X	2X	X	0

Regenerated LANA.75 Summary


- Crystallinity restored as measured by XRD
- Released significant fraction of He-3 trapped in the metal
- Reduced/eliminated "heel" of hydrogen trapped in the metal
- Restored reversible capacity of the hydride
- Exhibited a higher plateau pressure than a "virgin" sample
 - Differences in sample heating?
 - Loss of aluminum?







Thermal Stability Test System




Savannah River National Laboratory

Thermal Stability Test Plan


Load sample to test cell (~5 g) Activate hydride/perform heel exchanges on hydride in test cell at 80 °C

Test Activities

- Collect verification isotherm at 80 °C
- Recover pre-anneal material for analytical testing (~1.5 g)
- Collect pre-anneal isotherms at 80, 100, and 120 °C
- Anneal under vacuum at 750°C for 200 hours
- Collect post-anneal isotherms at 80, 100, and 120 °C
- Recover post-anneal material for analytical testing – Particle Size, ICP, XRD, SEM (~1.5 g)




Thermal Stability Testing – Pre-Anneal Isotherms



Savannah River National Laboratory

Thermal Stability Testing – Post-Anneal Isotherms




Savannah River National Laboratory

We put science to work.™

Thermal Stability Testing – Particle Size Analysis and ICP-ES Results

	Μ V (μm)	MA (μm)	ΜΝ (μm)	σ (μm)
Virgin Material	548.6	474.6	148.5	120.1
Pre-Anneal Material	17.98	14.45	9.04	8.17
Post-Anneal Material	21.37	18.83	13.42	6.97




	Composition		
Virgin Material	La _{1.00} Ni _{4.21} Al _{0.77}		
Pre-anneal Material	La _{1.00} Ni _{4.20} Al _{0.74}	No loss of Al	
Post-anneal Material	La _{1.00} Ni _{4.24} Al _{0.72}		


* Ca and Mg also detected above instrument detection limits, but were 3-5 orders of magnitude lower than La, Ni, or Al.




Thermal Stability Testing – XRD Results




- Little to no contamination of the material
- Heating the material does not change the crystalline structure




Thermal Stability Testing – SEM Results




- Cracks form when virgin material is exposed to hydrogen due to decrepitation
- Unusual growths appeared on the postanneal material



Thermal Stability Testing – Growths on Post-Anneal Material





EDS performed on all materials

- Flat surfaces show La, Ni, and Al as chemical composition
- Growths on virgin and post-anneal materials show excess oxygen
- Growths are oxides due to passivation of pre-anneal material?



Conclusions / Path Forward

Conclusions

- Pre-anneal material and post-anneal material isotherms have similar shapes, but the plateau region of the post-anneal material is flatter
- Particle size analysis showed that the pre-anneal and post-anneal material had similar sizes
- ICP analysis showed no significant changes in the elemental composition
- XRD analysis showed that there was no change in the crystalline structure due to heating
- SEM analysis showed growths on the post-anneal material

Path Forward


 Additional testing on the material with no passivation or recovery of sample prior to the annealing process



Acknowledgements

Financial support from the Savannah River Tritium Enterprises (SRTE) Engineering and Operations, Savannah River Field Office, and National Nuclear Security Administration (NNSA) Technology Maturation Division (NA-123.2) for the Plant Directed Research and Development (PDRD) program is gratefully acknowledged.

Sincere thanks to the many people who aided in this work: Kirk Shanahan, Robbie Allgood, Henry Ajo, and David Missimer.



Thank you for your attention

Questions?

