

**Contract No:**

This document was prepared in conjunction with work accomplished under Contract No. 89303321CEM000080 with the U.S. Department of Energy (DOE) Office of Environmental Management (EM).

**Disclaimer:**

This work was prepared under an agreement with and funded by the U.S. Government. Neither the U.S. Government or its employees, nor any of its contractors, subcontractors or their employees, makes any express or implied:

- 1 ) warranty or assumes any legal liability for the accuracy, completeness, or for the use or results of such use of any information, product, or process disclosed; or
- 2 ) representation that such use or results of such use would not infringe privately owned rights; or
- 3) endorsement or recommendation of any specifically identified commercial product, process, or service.

Any views and opinions of authors expressed in this work do not necessarily state or reflect those of the United States Government, or its contractors, or subcontractors.

SRNL-STI-2021-00399



# Optimization of CZTS Gamma-Ray Detectors

, Giuseppe S. Camarda<sup>1</sup>, Utpal N. Roy<sup>2</sup>, Yonggang Cui<sup>1</sup>, Ge Yang<sup>3</sup> and Ralph B. James<sup>2</sup>

<sup>1</sup>Brookhaven National Laboratory, Upton, NY, USA.

<sup>12</sup>Savannah River National Laboratory, Aiken, SC, USA.

<sup>3</sup>North Carolina State University, Raleigh, NC, USA.

**INMM-ESARDA Annual Meeting 2021**

**Live Thematic Poster Session I**

**8/25/2021 10:45:00 AM - 8/25/2021 12:30:00 PM**




# Optimization of CZTS Gamma-Ray Detectors: Selenium Concentration

- Some benefits of Se in CdZnTe matrix
    - Strong influence in modifying Zn segregation coefficient: better compositional homogeneity with increased Se concentration for THM grown ingots.
    - Effective solution hardening in arresting sub-grain boundaries and their network.
    - Decreased Te-inclusion/precipitate concentration.
  - Factors to be considered for optimizing the CdZnTeSe composition
    - Retrograde solubility of tellurium with Zn concentration variation
    - Band-gap variation of the composition
    - Role of Se on carrier trapping for point defects, complexes and any extended defects
1. Higher Zn concentration: higher concentration of Te inclusions/precipitates.
  2. Higher Zn concentration: higher alloy broadening.

## Band-gap variation of $\text{Cd}_{0.9}\text{Zn}_{0.1}\text{Te}_{1-y}\text{Se}_y$

Band-gap of  $\text{Cd}_{0.9}\text{Zn}_{0.1}\text{Te}_{1-y}\text{Se}_y$  vs. selenium concentration.



As the band-gap in CZTS decreases with increased selenium concentration, there is a tradeoff in finding the minimum amount of selenium compound for acceptable resistivity and the optimum CZTS composition for the lowest performance limiting defects.




# IR and LBNL ALS BL332 White Beam X-Ray Diffraction Topography (WBXDT)




Two techniques are being used to evaluate the presence of residual stress in CZTS:

- IR transmission under crossed polarizers: Stress-induced birefringence causes localized transmission of light through the sample.
- WBXDT: Topographic image reveals structural deformation due to stress induced lattice-distortion.

## Reflection geometry




WXRD images




**Residual thermal stresses are responsible for a non-uniform electric field distribution and sub-grain boundaries. A uniform electric field is critically important to attain high performing radiation detectors. Thus, avoidance and/or mitigation of high thermal stress in the materials is a strict requirement for enhanced detector performance.**

# X-ray topography and IR transmission image of THM-grown $\text{Cd}_{0.9}\text{Zn}_{0.1}\text{Te}_{0.985}\text{Se}_{0.015}$




High-magnification IR transmission microscopic images with two different magnifications.




Optical photograph and the corresponding X-ray topographic image of a  $\text{Cd}_{0.9}\text{Zn}_{0.1}\text{Te}_{0.985}\text{Se}_{0.015}$  sample.

The concentration and size of Te inclusions are comparable to as-grown CZT for CZTS with 1.5 atomic% of selenium. Thus, 1.5 atomic % of selenium composition is discarded, although the material is free from sub-grain boundary network.



High-magnification IR transmission microscopic images with two different magnifications.




Optical photograph and the corresponding X-ray topographic image of a  $\text{Cd}_{0.9}\text{Zn}_{0.1}\text{Te}_{0.98}\text{Se}_{0.02}$  sample.

The as-grown CZTS with 2 atomic% of selenium contains very low concentrations of Te inclusions. Additionally, the material is free from a sub-grain boundary network.

Apparently  $\text{Cd}_{0.9}\text{Zn}_{0.1}\text{Te}_{0.98}\text{Se}_{0.02}$  is the optimum composition with highly reduced performance limiting defects among the different compositions used in this study.

## Efficacy of Se addition in CZT matrix



As measured pulse height spectrum for a  $^{137}\text{Cs}$  source of a Frisch-grid detector fabricated from as-grown  $\text{Cd}_{0.9}\text{Zn}_{0.1}\text{Te}_{0.98}\text{Se}_{0.02}$  THM ingot. Left: IR transmitted image of the whole detector and right: X-ray topographic image of the whole detector. The inset shows the image of the fabricated detector.

Detector dimensions:  
 $3.5 \times 3.5 \times 9.15 \text{ mm}^3$ .

## Efficacy of Se addition in CZT matrix

- Enhanced compositional uniformity (about 90% of the ingot length)
- About 1.5 times increase of hardness as compared to CZT
- Reduced thermal stress
- Drastic reduction of Te inclusions
- Substantial reduction of sub-grain boundary and free from sub-grain network

## Charge Transport Properties of THM-grown CZTS with optimum 2% Se

Resistivity:  $1\text{-}3 \times 10^{10} \Omega\text{-cm}$

$\mu_{\text{Te}}$ :  $4.5\text{-}5 \times 10^{-3} \text{ cm}^2/\text{V}$  (average),  $6.6 \times 10^{-3} \text{ cm}^2/\text{V}$  (highest)

Detector performance: Energy resolution is 0.9-1.1 % at 662 keV,

(~1-cm long Frisch grid detectors) best resolution achieved: ~0.77 % at 662 keV.

**The composition with 2% Se ( $\text{Cd}_{0.9}\text{Zn}_{0.1}\text{Te}_{0.98}\text{Se}_{0.02}$ ) was found to be the best in terms of material properties and charge transport characteristics.**

**We expect to improve the energy resolution (as measured) at 662 keV to between 0.5-0.6 % for THM-grown  $\text{Cd}_{0.9}\text{Zn}_{0.1}\text{Te}_{0.98}\text{Se}_{0.02}$  by using purified starting material.**

Thank you for your kind attention !