#### **Contract No:**

This document was prepared in conjunction with work accomplished under Contract No. 89303321CEM000080 with the U.S. Department of Energy (DOE) Office of Environmental Management (EM).

#### Disclaimer:

This work was prepared under an agreement with and funded by the U.S. Government. Neither the U.S. Government or its employees, nor any of its contractors, subcontractors or their employees, makes any express or implied:

- 1) warranty or assumes any legal liability for the accuracy, completeness, or for the use or results of such use of any information, product, or process disclosed; or
- 2) representation that such use or results of such use would not infringe privately owned rights; or
- endorsement or recommendation of any specifically identified commercial product, process, or service.

Any views and opinions of authors expressed in this work do not necessarily state or reflect those of the United States Government, or its contractors, or subcontractors.

# FA<sub>3</sub>Bi<sub>2</sub>I<sub>9</sub>: An emerging Lead-Free Perovskite for Radiation Detection

Doup Kim, Ge Yang\*
Department of Nuclear Engineering, North Carolina State University
Ralph B. James
Savannah River National Laboratory

\*Ge Yang (phone: 919-515-5267, email: gyang9@ncsu.edu)

2022 SPIE OPTICS+PHOTONICS CONFERENCE

#### **Outline**

- Background and Motivation
- Study Approach
  - Crystal Growth
  - General Properties
  - Electrical Characteristics
  - X-ray Response
  - Mechanical Properties
- Conclusion and Future Study


## **Background and Motivation (1/3)**

#### Ionizing radiation detector R&D --- driven by applications

- Homeland security
- Medical diagnosis
- Industrial nondestructive inspection, etc.

#### **Semiconductor Detector (Direct detection)**

- High detection efficiency
- Tunable bandgap
- Excellent charge transport properties




Compared to indirect detection systems such as scintillators, semiconductor radiation detectors can offer much higher energy resolution

## **Background and Motivation (2/3)**

- Perovskite: a new class of radiation detector material
  - High stopping power & absorption coefficient
  - Long carrier lifetime & High carrier mobility
  - Cost-effective manufacturing process
- Lead (Pb)-based Perovskites
  - Lead (Pb)-based perovskites, such as  $ABX_3$  ( $A = CH_3NH_3$  and CS; B = Pb and Sn; X = I, Br, and Cl) family, have shown promising performance.
  - However, the toxicity of lead to both environment and human health poses realistic concerns.


## **Background and Motivation (3/3)**


- $FA_3Bi_2I_9$ : Lead-free formamidinium bismuth iodide perovskite
  - $(FA = CH(NH_2)_2)$ 
    - One of the  $A_3Bi_2I_9$  [A = Cs, MA (=  $CH_3NH_3$ )] perovskites family
    - Bismuth (Bi)-based perovskite: Non-toxic
    - Reasonable bandgap: ~2.1 eV
    - Material availability with high resistivity
    - Controllable growth and fabrication processes
    - FA<sub>3</sub>Bi<sub>2</sub>I<sub>9</sub> thin films were first explored by Lan et al. for solar cells in 2019
    - Potential X-ray detection was proposed by Li et al. in 2021




W. Li, D. Xin, S. Tie, J. Ren, S. Dong, L. Lei and W. H. Zhang, Zero-Dimensional Lead-Free FA3Bi2I9 Single Crystals for High-Performance X-ray Detection, J. Phys. Chem. Lett., 2021, 12(7), 1778–1785.

## We successfully grew large FA<sub>3</sub>Bi<sub>2</sub>I<sub>9</sub> Crystals








Color: Dark-red

Shape: hexagonal






Size:

• Area: up to  $1.5 \times 1.5 cm^2$ 


Thickness: up to 3 mm

#### General Properties of as-grown FA<sub>3</sub>Bi<sub>2</sub>I<sub>9</sub> Crystals

Cross-section Data from XCOM





Single Crystal XRD Results



## **General Properties** (2/2)

UV-vis measurement for bandgap






#### **Tauc Equation**

$$(\alpha \cdot hv)^{1/\gamma} = B(hv - E_g)$$

- $\alpha$ : absorption index
- γ: ½ for direct bandgap,
   2 for indirect bandgap


## **Electrical Properties (1/2)**

- Fabrication of Ag/FA<sub>3</sub>Bi<sub>2</sub>I<sub>9</sub>/Ag
   Detector Device
- Test Box




Crystal sample & Copper plate

Resistivity



# **Electrical Properties (2/2)**

Space-charge-limited current (SCLC)





$$V_{TFL} = \frac{qn_{trap}L^2}{\varepsilon_0\varepsilon_r}$$

- $n_{trap}$ : Trap density
- L: Sample thickness
- *V<sub>TFL</sub>*: Trap-filled limit voltage
- $\varepsilon_0$ : Vacuum dielectric constant
  - $\boldsymbol{\varepsilon_r}$ : Relative dielectric constant

## X-ray Response


X-ray Response Linearity






# X-ray Response

•  $\mu\tau$  product




Saturated current  $(I_0)$  at around 300 bias voltage

Sensitivity




# X-ray Response

Signal-Noise Ratio (SNR) of current




SNRs decreased until around 100 V bias. After 100 V bias, less change occurs.

Bias Dependence and Stability



# **Mechanical Properties**

#### Nanoindentation



The {001} plane was selected for nanoindentation according to XRD results

#### **Nanoindentation Results**

- Mean contact depth: 644.643 nm
- Std. dev of contact depth: 142.232 nm
- Mean hardness (*H*): 0.357 GPa
- Std. dev of hardness (H): 0.036 GPa
- Mean Young's modulus (E): 5.101 GPa
- Std. dev of Young's modulus (E): 0.42 GPa

The values of hardness (H) and Young's modulus (E) are highly reliable with low standard deviation.

#### Conclusion

#### Conclusion

- Large  $FA_3Bi_2I_9$  single crystals have been successfully grown.
- Appropriate bandgap energy and high resistivity for radiation detector applications
- High X-ray linearity and On/Off ratio, high  $\mu\tau$  product, low trap density
- Stability to long exposure of X-rays



#### On-going work

- Cathodoluminescence (CL) and photoluminescence (PL) measurements
- Gamma-ray and alpha particle spectroscopy measurements
- Stability measurements to different environment (humidity, temperature, etc.)

# Thank you for your attention!